



Mailing Address:
PO Box 1674
Warsaw, IN 46581-1674

Phone: 844-SEYMOUR
FAX: 574-267-8508
www.seymourmidwest.com

Shipping Address:
2666 S Country Club Rd
Warsaw, IN 46580


Stainless Steel Scraper **Assembly Instructions**

Tools Needed for Assembly:

- 7/16" wrench (two)


Parts Shipped with Unit:

- Blade (8, 12, or 16")
- Aluminum handle (not pictured)
- Gusset brace (set of 2)
- Bolt bag for braces



Gusset Brace Instructions:

1. Slide slotted handle over the center hole on the blade.
2. Position one gusset on the bottom of the handle, and the other gusset on top of the handle.
3. Insert the two longest bolts through the top gusset, the handle and the bottom gusset. Insert the two shorter bolts through the two remaining holes on the frame.
4. Tighten all nuts, being careful not to over-tighten. Over-tightening hardware may result in crushing the handle, thereby compromising its strength.



FULL WARRANTY

All Seymour Midwest products carry a full warranty against manufacturer defects in quality and workmanship. Products which have been abused or worn out from normal use are excluded from this warranty. We reserve the right to replace or issue credit on an individual basis.

REPLACEMENT PARTS LIST

See Reverse Side

PK90284
01/21/15

SCRAPER REPLACEMENT PARTS

SP50027 Blade – 4" x 8", stainless steel
SP50028 Blade – 4" x 12", stainless steel
SP50029 Blade – 4" x 16", stainless steel
SA30009 Braces - Gusset (Set of 2)
SA20172 Handle - 66" yellow aluminum powder-coated w/black grip
SA20171 Handle - 82" yellow aluminum powder-coated w/black grip
SA60023 Bolt bag: 4 bolts, 4 loc nuts (for handle attachment)
SP50002 Grip – 6" black